

STANDARD BANQUETTE INSTALL INSTRUCTIONS

Botton and gardiner assumes a level floor (scribing by others)

- 1) Remove Transport skid on base perimeter by unscrewing from base & remove cushions to reveal internal carcass.
- 2) Fix off LH & RH modules together by screwing together adjoining carcasses.
- 3) Place the carcass in desired location and fix down per options below:
 - A) either secure a bracket to the inside of the HMR carcass and fix to the floor (this stops vertical and horizontal movement) OR;
 - B) Screw a timber cleat/locator to the floor and place carcass over the top (this stops horizontal movement). Carcass can be fixed to cleat.
- 4) Replace cushions.
- 5) Silicone to base and floor junction.

All hardware /anchors /cleats / silicone and brackets by installer per standard installation practices.